iPhone
User Guide

For iOS 7 Software

Contents

8 Chapter 1: iPhone at a Glance
8 iPhone overview
9 Accessories
10 Multi-Touch screen
10 Buttons
12 Status icons

14 Chapter 2: Getting Started
14 Install the SIM card
14 Set up and activate iPhone
15 Connect iPhone to your computer
15 Connect to Wi-Fi
16 Connect to the Internet
16 Set up mail and other accounts
16 Apple ID
17 Manage content on your iOS devices
17 iCloud
18 Sync with iTunes
19 Date and time
19 International settings
19 Your iPhone name
20 View this user guide on iPhone

21 Chapter 3: Basics
21 Use apps
23 Customize iPhone
25 Type text
27 Dictate
28 Voice Control
29 Search
29 Control Center
30 Alerts and Notification Center
31 Sounds and silence
31 Do Not Disturb
31 AirDrop, iCloud, and other ways to share
32 Transfer files
33 Personal Hotspot
33 AirPlay
34 AirPrint
34 Use an Apple headset
35 Bluetooth devices
35 Restrictions

36 Privacy
36 Security
38 Charge and monitor the battery
39 Travel with iPhone

40 Chapter 4: Siri
40 Make requests
41 Tell Siri about yourself
41 Make corrections
42 Siri settings

43 Chapter 5: Phone
43 Phone calls
46 Visual voicemail
47 Contacts
47 Call forwarding, call waiting, and caller ID
47 Ringtones and vibrations
47 International calls
48 Phone settings

49 Chapter 6: Mail
49 Write messages
50 Get a sneak peek
50 Finish a message later
50 See important messages
51 Attachments
52 Work with multiple messages
52 See and save addresses
53 Print messages
53 Mail settings

54 Chapter 7: Safari
54 Safari at a glance
54 Search
55 Browse
55 Bookmark
56 Share
56 AutoFill
56 Reader
57 Reading list
57 Privacy and security
57 Safari settings

58 Chapter 8: Music
58 iTunes Radio
59 Get music
59 Browse and play
61 Album Wall
61 Audiobooks
61 Playlists
62 Genius—made for you

62 Siri and Voice Control
63 iTunes Match
63 Home Sharing
64 Music settings

65 Chapter 9: Messages
65 SMS, MMS, and iMessages
65 Send and receive messages
66 Manage conversations
67 Share photos, videos, and more
67 Messages settings

68 Chapter 10: Calendar
68 Calendar at a glance
68 Invitations
69 Use multiple calendars
70 Share iCloud calendars
70 Calendar settings

71 Chapter 11: Photos
71 View photos and videos
72 Organize your photos and videos
72 iCloud Photo Sharing
73 My Photo Stream
74 Share photos and videos
75 Edit photos and trim videos
75 Print photos
75 Photos settings

76 Chapter 12: Camera
76 Camera at a glance
77 Take photos and videos
78 HDR
78 View, share, and print
79 Camera settings

80 Chapter 13: Weather

82 Chapter 14: Clock
82 Clock at a glance
83 Alarms and timers

84 Chapter 15: Maps
84 Find places
85 Get more info
85 Get directions
86 3D and Flyover
86 Maps settings

87 Chapter 16: Videos
87 Videos at a glance
88 Add videos to your library

88 Control playback
89 Videos settings

90 Chapter 17: Notes
90 Notes at a glance
91 Use notes in multiple accounts

92 Chapter 18: Reminders
93 Scheduled reminders
93 Location reminders
93 Reminders settings

94 Chapter 19: Stocks

96 Chapter 20: Game Center
96 Game Center at a glance
97 Play with friends
97 Game Center settings

98 Chapter 21: Newsstand
98 Newsstand at a glance

99 Chapter 22: iTunes Store
99 iTunes Store at a glance
99 Browse or search
100 Purchase, rent, or redeem
100 iTunes Store settings

101 Chapter 23: App Store
101 App Store at a glance
102 Find apps
102 Purchase, redeem, and download
103 App Store settings

104 Chapter 24: Passbook
104 Passbook at a glance
104 Passbook on the go
105 Passbook settings

106 Chapter 25: Compass
106 Compass at a glance
107 On the level

108 Chapter 26: Voice Memos
108 Voice Memos at a glance
108 Record
109 Listen
109 Move recordings to your computer

110 Chapter 27: FaceTime
110 FaceTime at a glance
111 Make and answer calls

111 Manage calls

112 Chapter 28: Contacts
112 Contacts at a glance
113 Use Contacts with Phone
113 Add contacts
114 Contacts settings

115 Chapter 29: Calculator

116 Chapter 30: Nike + iPod
116 At a glance
116 Link and calibrate your sensor
117 Work out
117 Nike + iPod Settings

118 Appendix A: Accessibility
118 Accessibility features
118 Accessibility Shortcut
119 VoiceOver
129 Siri
130 Zoom
130 Invert Colors
130 Speak Selection
130 Speak Auto-text
131 Large and bold text
131 Reduce screen motion
131 Display on/off switch labels
131 Hearing aids
132 Subtitles and closed captions
133 LED Flash for Alerts
133 Mono Audio
133 Route the audio of incoming calls
133 Assignable ringtones and vibrations
133 Ambient Noise Cancellation
133 Guided Access
134 Switch Control
137 AssistiveTouch
137 TTY support
137 Visual voicemail
138 Widescreen keyboards
138 Large phone keypad
138 Voice Control
138 Accessibility in OS X

139 Appendix B: iPhone in Business
139 Mail, Contacts, and Calendar
139 Network access
139 Apps

141 Appendix C: International Keyboards
141 Use international keyboards
142 Special input methods

143 Appendix D: Safety, Handling, & Support
143 Important safety information
145 Important handling information
146 iPhone Support site
146 Restart or reset iPhone
146 Reset iPhone settings
147 Get information about your iPhone
147 Usage information
148 Disabled iPhone
148 Back up iPhone
149 Update and restore iPhone software
149 Cellular settings
150 Sell or give away iPhone?
150 Learn more, service, and support
151 FCC compliance statement
152 Canadian regulatory statement
152 Disposal and recycling information
153 Apple and the environment

iPhone at a Glance

1

iPhone overview

This guide describes the features of iOS 7, and of iPhone 4, iPhone 4S, iPhone 5, iPhone 5c, and iPhone 5s.

iPhone 5s



iPhone 5c



Your iPhone features and apps may vary depending on the model of iPhone you have, and on your location, language, and carrier. To find out which features are supported in your area, see www.apple.com/ios/feature-availability.

Note: Apps that send or receive data over a cellular network may incur additional fees. Contact your carrier for information about your iPhone service plan and fees.

Accessories

The following accessories are included with iPhone:



Apple headset. Use the Apple EarPods with Remote and Mic (iPhone 5 or later) or the Apple Earphones with Remote and Mic (iPhone 4S or earlier) to listen to music and videos, and make phone calls. See Use an Apple headset on page 34.

Connecting cable. Using the Lightning to USB Cable (iPhone 5 or later) or the 30-pin to USB Cable (iPhone 4S or earlier), connect iPhone to your computer to sync and charge.



Apple USB power adapter. Use with the Lightning to USB Cable or the 30-pin to USB Cable to charge the iPhone battery.

SIM eject tool. Use to eject the SIM card tray. (Not included in all areas.)

Multi-Touch screen

The Multi-Touch screen displays a wealth of info, entertainment, and creativity, all at your fingertips. A few simple gestures—tap, drag, swipe, and pinch—are all you need to explore and use iPhone apps.



Buttons

Most of the buttons you use with iPhone are virtual ones on the touchscreen. A few physical buttons control basic functions, such as turning iPhone on or adjusting the volume.

Sleep/Wake button

When you're not using iPhone, press the Sleep/Wake button to lock iPhone. Locking iPhone puts the display to sleep, saves the battery, and prevents anything from happening if you touch the screen. You can still get phone calls, FaceTime calls, text messages, alarms, and notifications. You can also listen to music and adjust the volume.

iPhone locks automatically if you don't touch the screen for a minute or so. To adjust the timing, go to Settings > General > Auto-Lock.

Turn iPhone on. Press and hold the Sleep/Wake button until the Apple logo appears.

Unlock iPhone. Press either the Sleep/Wake or Home button, then drag the slider.

Turn iPhone off. Press and hold the Sleep/Wake button until the red slider appears, then drag the slider.

For additional security, you can require a passcode to unlock iPhone. Go to Settings > General > Passcode & Fingerprint (iPhone 5s) or Settings > General > Passcode Lock (other models). See Use a passcode with data protection on page 36.

Home button

The Home button takes you to the Home screen, and provides other convenient shortcuts.

See apps you've opened. Double-click the Home button. See Start at home on page 21.

Use Siri (iPhone 4S or later) or Voice Control. Press and hold the Home button. See Voice Control on page 28 and Chapter 4, Siri, on page 40.

On iPhone 5s, you can use the sensor in the Home button to read your fingerprint, instead of using your passcode or Apple ID. See Touch ID sensor on page 37.

You can also use the Home button to turn accessibility features on or off. See Accessibility Shortcut on page 118.

Volume controls

When you're on the phone or listening to songs, movies, or other media, the buttons on the side of iPhone adjust the audio volume. Otherwise, the buttons control the volume for the ringer, alerts, and other sound effects.

WARNING: For important information about avoiding hearing loss, see Important safety information on page 143.



Lock the ringer and alert volumes. Go to Settings > Sounds and turn off "Change with Buttons." To limit the volume for music and videos, go to Settings > Music > Volume Limit.

Note: In some European Union (EU) countries, iPhone may warn that you're setting the volume above the EU recommended level for hearing safety. To increase the volume beyond this level, you may need to briefly release the volume control. To limit the maximum headset volume to this level, go to Settings > Music > Volume Limit and turn on EU Volume Limit. To prevent changes to the volume limit, go to Settings > General > Restrictions.

You can also use either volume button to take a picture or record a video. See Take photos and videos on page 77.

Ring/Silent switch

Flip the Ring/Silent switch to put iPhone in ring mode or silent mode .



In ring mode, iPhone plays all sounds. In silent mode, iPhone doesn't ring or play alerts and other sound effects.