

bacteriatest

rapid test for pools and spas

The **Watersafe**® Bacteria test is an antibody-based rapid test kit for the presence of bacteria in swimming pools and spas. The **Watersafe**® Bacteria Test detects *E.coli*, *Pseudomonas aeruginosa*, species of *Shigella*, *Enterobacter*, and many other coliform and non-coliform bacteria.

before you begin...


- 1. Each foil packet contains**
 - Test Strip
 - Sample Vial
 - Sample Dropper Pipette
 - Desiccant (to be discarded)
- 2. Do not open the foil packet until immediately prior to use.**
- 3. Use the sample vial provided to run the test.**
- 4. Sample pool water at the shallow end of the pool.**
- 5. Do not re-use any test strips, droppers, or vials.**
- 6. Store test at 50-86°F (10-30°C).**

For more information, please contact Silver Lake Research Corporation.
Tel. 626-359-8441 Fax. 626-359-6601 P.O. Box 686, Monrovia, CA 91017
www.discovertesting.com



Instructions for use

1. Open foil pouch and take out all contents.
2. Using a clean dropper, place *exactly* ONE dropper-ful of water into the sample vial. To draw up sample, tightly squeeze the bulb at the end of the dropper and place the open end into water sample. Release the bulb to pick up sample, then squeeze again to expel sample into vial.
3. Gently swirl vial. Let stand seven (7) minutes. Swirl vial again and return vial to flat surface.
4. Place test strip into sample vial with arrows pointing down.
5. Wait 10 minutes. *Do not disturb strip or vial during this time.* Reddish lines will appear on strips.
6. Take strip out of the vial and read results:

Negative: Only one line, next to number 2, is present.



Positive: Line 1 and Line 2 are present. Line 1 may be lighter in intensity or equal in intensity to line 2.



If only line 2 is present, test is NEGATIVE
If line 1 and line 2 are present, test is POSITIVE

If no lines appear, the test is not valid. Repeat procedure, starting with Step 1, with a new test kit.

IF THE TEST IS POSITIVE, YOUR WATER SAMPLE MAY CONTAIN BACTERIA LEVELS THAT ARE DANGEROUS TO YOUR HEALTH.

Please note that **Watersafe®** is a screening test and cannot be used to certify water as safe or unsafe. **Watersafe®** provides approximate results **ONLY** when used in strict accordance with instructions. Silver Lake Research Corporation expressly disclaims any liability resulting from use of this product, failure to follow instructions, or reliance on test results.